

Aim: Setup and configure a LAN (local area network) using a switch and Ethernet cables in your lab.

What is a LAN?

A Local Area Network (LAN) refers to a network that connects devices within a limited area, such as an office building, school, or home. It enables users to share resources, including data, printers, and internet access. LAN connects devices to promote collaboration and transfer information between users, such as computers, printers, servers, and switches. An LAN switch serves as the primary connecting device, managing and directing communications within the local network.

How to set up a LAN

- 1) Plan and Design an appropriate network topology taking into account network requirements and equipment location.
- 2) You can take 4 ~~Computers~~ Computers a switch with 8, 16, or 24 ports which is sufficient for networks of these sizes, and 4 Ethernet cables.
- 3) Connect your computers to network switch via an Ethernet cable, which is as simple as plugging one end of the Ethernet

cable into your computer and The other end into your network switch.

4) Assign IP addresses to your PCs.


1. Log on to The client computers as administrator or as Owners.
2. click Network and Internet Connections
3. Right click Local area connection / Ethernet
→ go to Properties → select Internet Protocol (TCP/IPv4) → click on Properties
→ select use The following ip address option and assign ipaddress.

5) Configure a network switch.

1. Connect your computer to The switch
To access The switch's web interface, you will need to connect your computer to The switch using an Ethernet cable.
2. Log in to The web interface. Open a web browser and enter The IP address of The switch's web interface.
Enter The username and password to log in.
3. Configure basic settings: Once you're logged in, you will be able to configure basic settings for The switch.
4. Assign IP address as: 10.1.1.5, subnet mask 255.0.0.0.

- 6) check The connectivity between switch and other machine by using ping command in The command prompt of The device.
- 7) select a folder, → go to properties → click sharing tab → share it with everyone on The same LAN.
- 8) Try to access The shared folder from other Computers of The network

student Observation



Result:

The connection have been done successfully.

[Signature]